




Dimensions



Connection Diagram



* Available only for DOL-03C/03CS
 ** Available only for DOL-03CS
 Note: For CT-25 models:
 k: When CT-25 is used, Red cable is connected to k terminal.
 t: When CT-25 is used, Black cable is connected to t terminal.

Summary of the Contact Operations *


	ALTERNATIVE 1 (U-)	ALTERNATIVE 2 (H-L)
Out 1	Current --> Under/Over	Voltage --> Under Frequency --> Under Current --> Under Phase Seq.
Out 2	Voltage --> Under/Over Frequency --> Under/Over Phase Seq.	Voltage --> Over Frequency --> Over Current --> Over

* Valid for DOL-03C/03CS


INDEX

Precautions for Installation and Safe Usage.....1
 Front Panel and Usage of Buttons.....1
 General Information and Applications.....1
 Using the Buttons.....1
 Transformer Menu (Tr Imp /Ur /ConECon).....2
 User Password Settings (Pin Menu).....2
 Activating the User Password (Pin Act Menu).....2
 Changing the User Password (Pin Chg Menu).....2
 Output Setting Menu.....2
 Current Setting Menu (SP Current Menu).....3
 High/Low Current Settings (SP Cur Hi, SP Cur Lo Menu).....3
 Hysteresis Settings for High/Low Currents (I-H Hys, I-L Hys Menu).....3
 Delay-on Time for High/Low Currents (I-H ond, I-L ond Menu).....3
 Delay-off Time for High/Low Currents (I-H ofd, I-L ofd Menu).....3
 Start and Auto Function (StArt dEL and Auto rSt Menu).....4
 Instant Trip Function (CUr inSt rP Menu).....4
 Voltage Setpoint Menu (SP Volt Menu).....4
 High/Low Voltage Settings (SP Vol, H, SP Vol, Lo Menu).....4
 Hysteresis Settings for High/Low Voltages (U-H Hys, U-L Hys Menu).....5
 Delay-on Time for High/Low Voltages (U-H ond, U-L ond Menu).....5
 Delay-off Time for High/Low Voltages (U-H ofd, U-L ofd Menu).....5
 Frequency Menu.....5
 High/Low Frequency Settings (Frq Hi, Frq Lo Menu).....6
 Hysteresis Settings for High/Low Frequencies (F-H Hys, F-L Hys).....6
 Delay-on / Delay-off Time for High/Low Frequencies (Frq ond, Frq ofd).....6
 Phase Sequence (Voltage Sequence Menu) and Instant Trip (Vol inSt rP Menu) Menu.....6
 Erasing the Max., Min. and Max. Demand Values (Reset Menu).....6
 Demand Time for Demand and Max. Demand (dE InSt Menu).....7
 Communication Menu (RS-485).....7
 Technical Features and Default Factory Settings.....7
 Connection Diagram.....7
 Output, SP Current and SP Volt menus are available for DOL-03C/03CS; RS-485 menu is available for DOL-03CS.


PRECAUTIONS FOR INSTALLATION AND SAFE USE
 In CT-25 (120A) compliant models, only CT-25 current transformer must be used.
 Other type of CT's have a high risk to damage to device.
 Failure to follow those instructions will result in death or serious injury.
 - Disconnect all power before working on equipment.
 - When the device is connected to the network, do not remove the front panel.
 - Do not try to clean the device with solvent or the like. Only clean with dry cloth.
 - Verify correct terminal connections when wiring.
 - Electrical equipment should be serviced only by your component seller.
 - Only for rack panel mounting.
 - Fuse must be F type and limit value doesn't exceed 1A.
 - No responsibility is assumed by manufacturer or any of its subsidiaries for any consequences arising out of the use of this material.



- Phase LEDs. The LEDs turn on when the voltage value, which is applied to one of the current inputs, reach 30 V
- First display's k LED (for L1). Measurement parameter is the unit of kilo when LED is turned on. ie: kA, kV
- Display for L1.
- Second display's k LED (for L2). Measurement parameter is the unit of kilo when LED is turned on. ie: kA, kV
- Display for L2.
- Third display's k LED (for L3). Measurement parameter is the unit of kilo when LED is turned on. ie: kA, kV
- Display for L3.
- Displays network frequency when Hz LED is turned on.
- k LED for neutral current. Measurement parameter is displayed in unit of kilo when this LED is turned on.
- Display for neutral current and frequency (for DOL-03C/03CS).
- First warning output LED (Out1). Turned on when the output is activated.
- Second warning output LED (Out2). Turned on when the output is activated.
- Over current / voltage warning output for L1. (DOL-03C/03CS)
- Low current / voltage warning output for L1. (DOL-03C/03CS)
- Over current / voltage warning output for L2. (DOL-03C/03CS)
- Low current / voltage warning output for L2. (DOL-03C/03CS)
- Over current / voltage warning output for L3. (DOL-03C/03CS)
- Low current / voltage warning output for L3. (DOL-03C/03CS)
- Over current / frequency warning output for frequency and neutral current (DOL-03C/03CS).
- Low current / frequency warning output for frequency and neutral current (DOL-03C/03CS).
- Monitoring the L1, L2, L3 voltages values when V LED is turned on and displays the frequency in 4th display.
- Monitoring the L1, L2, L3 currents values when A LED is turned on and displays the neutral current in 4th display.
- Indicates the activating delta connection when Δ is turned on. Neutral current protection is deactivated even if is activated.
- H LED for max. instant current and voltage. Max. instant currents and voltages are displayed when this LED is turned on.
- L LED for min. instant current and voltage. Min. instant currents and voltages are displayed when this LED is turned on.
- M LED for max. demand. Max. demand values are displayed when this LED is turned on.
- SET button. It is used to enter into the menu and to save the values. If SET button is pressed for 3 sec. in the measurement mode, you can enter into menus. This button is used for monitoring the max. (H), Min. (L) current values and max. demand values in measurement mode.
- Downward selection button.
- Upward selection button.
- ESC button. Escaping from the menu. And also used for switching off the Latch function while this function has activated.



General information
 DOL-03/03C/03CS is designed for measuring Phase current, frequency, neutral current and voltages (Phase-Phase and Phase-Neutral) in a 3-Phase system.
 DOL-03C/03CS:
 Device has 2 warning output which named as Out1 and Out2. (NO-Normally Open) Please refer to "Output" menu for the functions of the relays.



Setpoints for Frequency :
In this menu, Frequency range can be defined according to High and Low values of Frequency measurement.
If the frequency of the system decreases the Frq Hi value; output is switched on and LED is turned on. (Refer to Output menu) and H LED for frequency is turned off.
If the frequency of the system exceeds the high set value, H LED relating to frequency blinks, output switched off at the end of defined time (Frq Ond), LED turned off (Refer to Output menu) and H LED for frequency is turned on continuously.
If the frequency of system are under the high set value (Frq Hi) as a hysteresis (F-H Hys), output is turned on at the end of defined time (Frq Ofd), LED is turned on and H LED is turned off, at the end of the adjusted time (Frq Ofd), output LED turns on and H LEDs turn off.
If the frequency of the system is over the low set value (Frq Lo), output is turned on, LED is turned on L LED is turned off.
If the frequency of the system decreases the low set value (Frq Lo), L LED blinks; output is turned off and L LED is turned on continuously.
If the frequency of the system is over the low set value (F-L Hys) as a hysteresis (Frq Hys), output is turned on at the end of defined time (Frq Ofd), LED is turned on and L LED is turned off.

Note: System frequency is measured for L1.

There are 6 submenus.
Frq Hi, Frq Lo, F-H Hys, F-L Hys, Frq Ond, Frq Ofd.

Frq Hi
Max. value for system frequency, this value can be defined between 0...70.00 Hz. If the value is set to zero (0), the high frequency warning is disabled.

Frq Lo
Min. value for system frequency, this value can be defined between 0...70.00 Hz. If the value is set to zero (0), the low frequency warning is disabled.

Note: Attention for common using of output and relay LED for voltage.

F-H Hys
In this menu, required hysteresis value can be defined between 0...20.00 Hz, in order to switching off the "high frequency" warning.

F-L Hys
In this menu, required hysteresis value can be defined between 0...20.00 Hz, in order to switching off the "low frequency" warning.

Frq Ond
Delay-on time for activation of alarm for high and low frequency value.
This value can be defined between 000.0...999.9 in term of seconds..

Frq Ofd
Delay-off time for deactivation of alarm for high and low frequency value.
This value can be defined between 000.0...999.9 in term of second..


Phase sequence can be turned on/off in this menu. Inversed phase voltage which is applied to the measurement inputs (L1-L2-L3), can be monitored. Default setting is off. In order to let the device to warn user in case of inversed phase situation please change the off position as on in "UoL PHS SEQ" menu. Phase sequence function is disabled if the selection is selected off.
L1, L2 and L3 LEDs blink and output output released immediately when "UoL PHS SEQ" is turned on and phase sequence is inversed with any reason.
Note: Output 2 is used if U-I is selected and Output1 is used if H-L is selected in Output menu for the Phase Sequence monitoring.

Instant Tripping Function.
At position ON, if any V-L / V-L-N values exceeds 1.5 times of high voltages (UoL Hi L1-L2/L-3) values; the "voltage output" switches OFF, instantly, output LED turned OFF and H LED, for related voltage, is turned ON. (Please refer to "Output".)
If any phase voltage decrease 0.5 times low voltages (UoL L1-L2/L-3); the "voltage output" switches OFF instantly, output LED turned OFF and L LED, for related voltage, is turned ON.


(Refer to Page-4 for "Cur inS trP", "Aut o rSt" and "UoL inS trP")

Reset function.
In this menu, values of min., max., max. demand are erased. It saves the instantaneously measured min. and max. values of the device into its memory. Please kindly look at the section of FUNCTIONS OF BUTTONS for min. and max. values.
Note: Measured electrical parameters which are saved to the memory are not affected from the electric interruptions. In the rES Et HL or rES Et dE menu; when you choose yES and quit from all menus, if you confirm the changes, min., max. and max. demand values of all parameters are erased at the same time.


Press SET button for 3 sec. (trA Fo menu is displayed.)
Find rES Et menu by scrolling UP-DOWN buttons.
Press SET button ("rES Et dE / rES Et HL no" is displayed.)
Find rES Et dE / rES Et HL menu by scrolling UP-DOWN buttons.




Press SET button ("rES Et dE no / rES Et HL no" is displayed.)
By using the UP-DOWN buttons, other parameters can be selected. If you want to delete the value, choose yES, if not choose no.



Demand Time.
Max. Demand time can be defined between 01-60 minute in this menu.
Press SET button for 3 sec. (trA Fo menu is displayed.)
Find dE t menu by scrolling UP-DOWN buttons.



Programming "SP Cur rnt" :
Using purposes of submenus of "SP Cur rnt" explained below with details.




Press SET button, "Pin CHA n9E" is displayed. (Data is entered but is not activated yet. For activating the new data please follow the below steps)

Press ESC button one by one until "SAU E SET yES" is displayed.

Press SET button, When "SAU E SET yES" is displayed (If you press ESC button or choose "no" option instead of "yES" then new data will be cancelled and previous value will be activated).

Press SET button, When "SAU E SET yES" is displayed (If you press ESC button or choose "no" option instead of "yES" then new data will be cancelled and previous value will be activated).



Output menu :
In this menu, using of oUt PUt function is explained with details below.

Out Relay function:
In this menu high-low or voltage-current monitoring is determined for Out1 and Out2 outputs.
Note: When U-I (voltage-current) is selected; Out2 is monitoring according to high or low voltage, frequency values and phase sequence, Out1 is monitoring according to high or low current value.
When H-L (high-low) is selected; Out2 is monitoring according to high values for voltage, frequency and low-current, Out1 is monitoring according to low values for voltage or current.
Please refer to page 8 for a summary of the contact operations.

Out Latch function:
If the Latch function is turned on; OUT1-OUT2 outputs, which are released when a failure has occurred, keep remained at its position even if the failure is over. Press [] button in order to triggering the relay when the failure situation is removed.
If the Latch function is turned off; Released outputs triggered at the end of delay off time when the failure situation is removed.


Out Inverse function:
If "oUt inU ErS" function is selected off; Device is started with closed output contacts (out1, out2) in the normal network conditions according to settings. Otherwise devices started with open position of the contacts. Default setting is "off".



Press SET button, oUt rEL AY is displayed. (Data is entered but is not activated yet. Activating the new data, please follow the below steps)

Press ESC button one by one until "SAU E SET yES" is displayed.

Press SET button, When "SAU E SET yES" is displayed (If you press ESC button or choose "no" option instead of "yES" then new data will be cancelled and previous value will be activated).



Programming "SP Cur rnt" :
Using purposes of submenus of "SP Cur rnt" explained below with details.



SP Cur rnt
In this menu, high set points for current values are programmed. H values for IL1, IL2, IL3 and IN can be entered one by one. If all the current values are under the Hi value; Out1 output is switched on, LED of Output1 turned on and LED of H turned off.
If any current (IL1, IL2, IL3 and IN) exceeds the high set value, H LED blinks; Output 1 output switches off at the end of the defined time (H-H ond). Output 1 LED turned off and H LED turned on continuously.
If all currents (IL1, IL2, IL3 and IN) are below the high set value (Hi) as a hysteresis current (H-H Hys), output 1 output switches on at the end of the defined time (H-H Ofd), output 1 LED turned on and H LED turned off.
This menu has 7 sub menus; I-L L-1, I-L L-2, I-L L-3, I-H L-1, I-H Hys, I-H ond, I-H ofd
Note: High Current values are programmed for IL1, IL2, IL3 and IN separately but I-H Hys (hysteresis), I-H ond (delay on time) and I-H Ofd (delay off time) values are common and they have same values for IL1, IL2, IL3 and IN.

SP Cur rnt
In this menu, low set points for current values are programmed. Lo values for IL1, IL2, IL3 and IN can be entered one by one. If all the current values are over the Lo value; Out1 output is switched on, LED of Output1 turned on and LED of L turned off.
If any current (IL1, IL2, IL3 and IN) exceeds the low set value, L LED blinks and Output 1 output switches off at the end of the defined time (L-L ond). Output 1 LED turned off and L LED turned on continuously.
If all currents (IL1, IL2, IL3 and IN) are over the low set value (Lo) as a hysteresis current (L-L Hys), output 1 output switches on at the end of the defined time (L-L Ofd), output 1 LED turned on and L LED turned off.
This menu has 7 sub menus; I-L L-1, I-L L-2, I-L L-3, I-L L-1, I-L Hys, I-L ond, I-L ofd
Note: Low Current values are programmed for IL1, IL2, IL3 and IN separately but I-L Hys (hysteresis), I-L ond (delay on time) and I-L Ofd (delay off time) values are common and they have same values for IL1, IL2, IL3 and IN.

I-H L-1
In this menu, max. current value for IL1 is programmed. The current value can be programmed between; 0.001...5,000 A (Cr = 1); 0.001...120.0 A (for CT-25 adapted device trm=1). If the value is set to zero (0), the high current warning is disabled (I-H L-2 and I-H L-3 are programmed similarly). Refer "SP Cur H" for details.
In this menu, min. current value for IL1 is programmed. The current value can be programmed between; 0.001...5,000 A (Cr = 1); 0.001...120.0 A (for CT-25 adapted device trm=1). If the value is set to zero (0), the low current warning is disabled (I-L L-2 and I-L L-3 are programmed similarly). Refer "SP Cur Lo" for details.

I-H Hys
In this menu, required hysteresis current for high current warning is programmed. (same for IL1, IL2, IL3 and IN.)
The current value can be programmed between; 0.001...2,500 A (Cr = 1)
0.001...120.0 A (for CT-25 adapted device trm=1)
Refer "SP Cur H" for details.

I-L L-1
In this menu, required hysteresis current for low current warning is programmed. (same for IL1, IL2, IL3 and IN.)
The current value can be programmed between; 0.001...2,500 A (Cr = 1)
0.001...120.0 A (for CT-25 adapted device trm=1)
Refer "SP Cur Lo" for details.

I-L L-2
Delay time for activating the output for high current warning. It is common for all currents (IL1, IL2, IL3 and IN).
The value can be programmed between 000.0 and 999.9 in terms of seconds.
(Refer "SP Cur H" for details.)

I-L L-3
Delay time for activating the output for low current warning. It is common for all currents (IL1, IL2, IL3 and IN).
The value can be programmed between 000.0 and 999.9 in terms of seconds.
(Refer "SP Cur Lo" for details.)

I-H ond
Delay time for releasing the output for high current warning. It is common for all currents (IL1, IL2, IL3 and IN).
The value can be programmed between 000.0 and 999.9 in terms of seconds.
(Refer "SP Cur H" for details.)

I-H ofd
Delay time for releasing the output for low current warning. It is common for all currents (IL1, IL2, IL3 and IN).
The value can be programmed between 000.0 and 999.9 in terms of seconds.
(Refer "SP Cur Lo" for details.)

I-L ond
Delay time for releasing the output for high current warning. It is common for all currents (IL1, IL2, IL3 and IN).
The value can be programmed between 000.0 and 999.9 in terms of seconds.
(Refer "SP Cur H" for details.)

I-L ofd
Delay time for releasing the output for low current warning. It is common for all currents (IL1, IL2, IL3 and IN).
The value can be programmed between 000.0 and 999.9 in terms of seconds.
(Refer "SP Cur Lo" for details.)

I-L L-2
Delay time for activating the output for high current warning. It is common for all currents (IL1, IL2, IL3 and IN).
The value can be programmed between 000.0 and 999.9 in terms of seconds.
(Refer "SP Cur H" for details.)

I-L L-3
Delay time for activating the output for low current warning. It is common for all currents (IL1, IL2, IL3 and IN).
The value can be programmed between 000.0 and 999.9 in terms of seconds.
(Refer "SP Cur Lo" for details.)

I-H Hys
Delay time for releasing the output for high current warning. It is common for all currents (IL1, IL2, IL3 and IN).
The value can be programmed between 000.0 and 999.9 in terms of seconds.
(Refer "SP Cur H" for details.)


I-H ofd
Delay time for releasing the output for low current warning. It is common for all currents (IL1, IL2, IL3 and IN).
The value can be programmed between 000.0 and 999.9 in terms of seconds.
(Refer "SP Cur Lo" for details.)

I-L L-1
Delay time for releasing the output for high current warning. It is common for all currents (IL1, IL2, IL3 and IN).
The value can be programmed between 000.0 and 999.9 in terms of seconds.
(Refer "SP Cur H" for details.)

I-L L-2
Delay time for releasing the output for low current warning. It is common for all currents (IL1, IL2, IL3 and IN).
The value can be programmed between 000.0 and 999.9 in terms of seconds.
(Refer "SP Cur Lo" for details.)

I-L L-3
Delay time for releasing the output for high current warning. It is common for all currents (IL1, IL2, IL3 and IN).
The value can be programmed between 000.0 and 999.9 in terms of seconds.
(Refer "SP Cur H" for details.)


Programming the "SP C_{Ur} Hi", "SP C_{Ur} Lo", "SP UoL Hi" and "SP UoL Lo".



Start-up delay:
Start Delay Time is used to prevent from faulty switchings caused by motor start-up current (demurrage current).
Out1 remain switched ON in this time period (When U-1 is selected). In this time period, even if the current value exceeds the limits device doesn't sense it as a warning. The device doesn't give a warning even if the current value isn't in the setting interval.
This function is used with "Auto Reset" function.


Auto Reset Function:
If **Auto Reset** function is selected as ON: Each time that the current decreases "50mAxCtr" value, start-up delay time is reset and when the current value increases "50mAxCtr", start-up delay function is activated.
If **Auto Reset** function is selected as OFF: If the power supply is switched off and then switched on, start-up delay function is activated.

Please refer to below graphics for the operating principle of STA r dEL and Aut o rSt functions



Instant Tripping Function.
At position ON, if any phase current (IL1, IL2, IL3 and IN) exceeds 1.5 times of high (I-H L-1, I-H L-2, I-H L-3, I-H L-n) values, the "current output" switches off instantly, output LED turned off and H LEDs for related currents turned on. (Please refer to "Output".)
At position OFF, if any phase current (IL1, IL2, IL3 and IN) decrease 0.5 times of low (I-L L-1, I-L L-2, I-L L-3, I-L L-n) values, the "current output" switches off instantly, output LED turned off and L LEDs for related currents turned on. (Please refer to "Output".)
At position OFF, instant tripping function is cancelled.

Programming "C_{Ur} inS trP", "Aut o rSt" and "UoL inS trP"



Programming "SP UoL t":
Using purposes of submenus of "SP UoL t" explained below with details.

In this menu, high set points for voltage values are programmed. Hi values for Phase-Neutral / Phase-Phase (according to Star / Delta selection) can be entered one by one.

If all the voltage values (Phase-Neutral / Phase-Phase) are under the Hi value; related relay is switched on, its LED turned on (please refer "Output") and related H LEDs are turned off.
If all the voltage values (Phase-Neutral / Phase-Phase) are over the Hi value; H LED blinks and related output is switched off at the end of "delay on time" (U-H ond), its LED turned off (please refer "Output") and related H LEDs are turned on.

If all voltage (Phase-Neutral / Phase-Phase) are below the high set value (Hi) as a hysteresis voltage (U-H HyS), related output is switched on at the end of the "delay off time" (U-H oFd), its LED turned on (please refer "Output") and H LED is turned off.
Note: High Voltage values are programmed for (Phase-Neutral / Phase-Phase) separately but "Hi HyS" (hysteresis) and "Hi ond" (delay on time) and "Hi oFd" (delay off time) values are common; these parameters have same values for Phase-Neutral / Phase-Phase.
When Connection type (Star/Delta) is selected (refer to Connection menu), device will change the U-H L-1, U-H L-2 and U-H L-3 values automatically according to connection.

Example: If the connection type is selected as Star (with neutral); U-H HyS=10V U-H L-1=250V, U-H L-2=255V, U-H L-3=260V and then this connection type is selected as Delta (without neutral), device will change the values after calculated them according to Phase-Phase values.
New values:
U-H L-1 (L1-L2 Phase to phase voltage) = 433 V
U-H L-2 (L2-L3 Phase to phase voltage) = 441 V
U-H L-3 (L3-L1 Phase to phase voltage) = 450 V
U-H-HyS = 10 V.
There are 6 submenus.
U-H L-1, U-H L-2, U-H L-3, U-H HyS, U-H ond, U-H oFd.


In this menu, low set points for voltage values are programmed. Lo values for Phase-Neutral / Phase-Phase (according to Star / Delta selection) can be entered one by one.
If all the voltage values (Phase-Neutral / Phase-Phase) are over the Lo value; related output is switched on, its LED turned on (please refer "Output") and related L LEDs are turned off.
If any of the voltage values (Phase-Neutral / Phase-Phase) decrease the Lo value, L LED blinks and related output is switched off at the end of "delay on time" (U-L ond), its LED turned off (please refer "Output") and related L LED is turned on continuously.
If all voltage (Phase-Neutral / Phase-Phase) values increase the low set value (Lo) as a hysteresis voltage (U-L HyS), related relay is switched on at the end of the "delay off time" (U-L oFd), its LED turned on (please refer "Output") and L LED is turned off.

Note: Low Voltage values are programmed for (Phase-Neutral / Phase-Phase) separately but "U-L HyS" (hysteresis), "U-L ond" (delay on time) and "U-L oFd" (delay off time) values are common; these parameters have same values for Phase-Neutral / Phase-Phase.
When Connection type (Star/Delta) is selected (refer to Connection menu), device will change the U-L L-1, U-L L-2 and U-L L-3 values automatically according to connection.
Example: If the connection type is selected as Star (with neutral); U-L HyS=10V
U-L L-1=180V, U-L L-2=175V, U-L L-3=170V and then this connection type is selected as Delta (without neutral), device will change the values after calculated them according to Phase-Phase values.
New values:
U-L L-1 (L1-L2 Phase to phase voltage) = 311 V
U-L L-2 (L2-L3 Phase to phase voltage) = 303 V
U-L L-3 (L3-L1 Phase to phase voltage) = 294 V
U-L-HyS = 10 V.
There are 6 submenus.
U-L L-1, U-L L-2, U-L L-3, U-L HyS, U-L ond, U-L oFd.


U-H ond High value for L1, when the Star is selected; high value for L1-L2, when the Delta selected can be defined in this menu.
0...300 for Star connection and 0...500 for Delta connection can be defined.
If the value is set to zero (0), the high voltage warning is disabled. Refer "SP UoL Hi" for details.
Note: L2 and L3 phases can be programmed similarly.
U-L ond Low value for L1, when the Star is selected; low value for L1-L2, when the Delta selected can be defined in this menu.
0...300 for Star connection and 0...500 for Delta connection can be defined.
If the value is set to zero (0), the high voltage warning is disabled. Refer "SP UoL Lo" for details.
Note: L2 and L3 phases can be programmed similarly.

U-H oFd Delay off time for activating the output for high voltage warning. It is common for all voltages (same for Phase-Neutral/Phase-Phase.)
The value can be programmed between 000.0 and 999.9 in terms of seconds. (Refer "SP UoL Hi" for details.)
U-L oFd Delay off time for activating the output for low voltage warning. It is common for all voltages (same for Phase-Neutral/Phase-Phase.)
The value can be programmed between 000.0 and 999.9 in terms of seconds. (Refer "SP UoL Lo" for details.)
U-H oFd Delay off time for activating the output for high voltage warning. It is common for all voltages (same for Phase-Neutral/Phase-Phase.)
The value can be programmed between 000.0 and 999.9 in terms of seconds. (Refer "SP UoL Lo" for details.)

Programming the "U-H ond", "U-H oFd", "U-L ond", "U-L oFd", "I-H ond", "I-H oFd", "I-L ond", "I-L oFd".



Programming the "U-H HyS", "U-L HyS", "I-H HyS", "I-L HyS"



U-H ond Delay off time for activating the output for high voltage warning. It is common for all voltages (same for Phase-Neutral/Phase-Phase.)
The value can be programmed between 000.0 and 999.9 in terms of seconds. (Refer "SP UoL Hi" for details.)
U-L ond Delay off time for activating the output for low voltage warning. It is common for all voltages (same for Phase-Neutral/Phase-Phase.)
The value can be programmed between 000.0 and 999.9 in terms of seconds. (Refer "SP UoL Lo" for details.)
U-H oFd Delay off time for activating the output for high voltage warning. It is common for all voltages (same for Phase-Neutral/Phase-Phase.)
The value can be programmed between 000.0 and 999.9 in terms of seconds. (Refer "SP UoL Hi" for details.)
U-L oFd Delay off time for activating the output for low voltage warning. It is common for all voltages (same for Phase-Neutral/Phase-Phase.)
The value can be programmed between 000.0 and 999.9 in terms of seconds. (Refer "SP UoL Lo" for details.)

U-H HyS In this menu, required hysteresis voltage for high voltage warning is programmed, (same for Phase-Neutral/Phase-Phase.)
0...200V for Star connection and 0...200V for Delta connection can be defined.
Refer "SP UoL Hi" for details.
U-L HyS In this menu, required hysteresis voltage for low voltage warning is programmed, (same for Phase-Neutral/Phase-Phase.)
0...200V for Star connection and 0...200V for Delta connection can be defined.
Refer "SP UoL Lo" for details.